

# Installation of lead flashings

(February 2024) (Second issue – supersedes December 2008)

The Technical Guidance Notes are produced by NHBC as guidance solely for our builder customers as to how to interpret the technical requirements in relation to the warranty cover provided by NHBC under its Buildmark, Buildmark Choice, Buildmark Link, Buildmark Solo, Buildmark Connect or any similar product from time to time. It has not been created or intended for distribution or use outside of that purpose. The information contained in this Technical Guidance Note does not constitute advice and is not to be relied upon by any third party. Nothing in this Technical Guidance Note is intended to, nor should it be taken to, create any legal or contractual relationship. Any third party who chooses to rely upon the information contained in the Technical Guidance Notes shall do so entirely at their own risk and NHBC accepts no duty of care or liability, however caused, in connection with its use or reliance by any third party.

## Question

Where lead flashings are to be installed under DPCs and cavity trays in masonry walls, should the mortar joints be raked out as the masonry work proceeds or can the joint be cut out later?

## Considerations

- NHBC Standards clause 6.1.17 states it is easier to rake out joints as work proceeds.
- The Lead Sheet Association provides guidance on installation of lead flashings which confirms this.
- Cutting out the joint once the mortar had hardened is likely to cause damage to DPCs and cavity trays, leading to water penetration.

## Answer

To avoid damage to DPCs and cavity trays the joint for lead flashings should be raked out to a depth of at least 25mm as work proceeds, as shown in the diagram below.

As an alternative, lead flashings can be built in as the work proceeds. They should be built in to a depth of 50mm and a welged edge should be provided to form a key with the mortar as shown in the diagram below.

